



Attach encoder assembly so the encoder wheel rides in the carriage wheel.
Place bolt through hole in the carriage as shown.



Attach cable chain with the two screws provided (as shown)



Make sure all parts and wires do not drag
on the frame.